



**Scientific technological Center**

Via Bovio 6 – 28100 Novara - NO - Italy

Tel +39 0321697200 - Fax +39 0321 688515 - Email: [info@etneo.com](mailto:info@etneo.com)

[www.etneo.com](http://www.etneo.com)

**OBJECT: ETX 101D INSTRUCTIONS**

The ETX 101D station is a digital desoldering station with a 50w 24v desoldering tool.

Here below some useful info on how to work with this station:

The green led show you that the power is on and the station is working good.

The red led show you that the tool is connected to the station and the heater is hot, when the led stop flashing it means that the heater has reach the selected temperature. On the side of the tool there is the switch to start the vacuum, put the nozzle on the pin you need to desolder then when tin is liquid push the button and the tin will go on the pyrex glass.

We suggest everyday when finish working to remove the tip from the tool and clean both with the specific cleaning tool to remove oxide and tin, to check the filters and silicon ring and to clean the pyrex glass with alcool and paper.